## Offset Taper Layout **Custom Rod** Take Circumference of blank at end of wrap and mark it I to J by CURT BAKER Take Circumference of blank at butt and mark it A to B Lined Notebook **Paper** Draw a line from B to J This will give you adjusted messurments C to D, E to F and G to H Measurements flip Draw Line From B to J Draw line to measure from I to J G to H E to F C to D A to B A to B C to D E to F G to H Half I to J

- 1. Draw line down left side notebook paper
- 2. Take circumference of butt and mark it out from line on left hand side this will be A to B
- 3. Use A to B measurement to estimate number of patterns to show (in this case 5)
- 4. Count down 4 lines this will be I to J
- 5. Take circumference of tip and mark it on 4th line down ( I to J )
- 6. Draw line from point B to point J
- 7. Take measurement I to J and mark it at the Butt end
- 8. Then G to H, E to F, C to D and A to B

NOTE: 1. remember to take only half of I to J for 180 degree marks